RDS1D



3P



4P

Switch Disconnector
Interrupteur Sectionneur
Interruptor Seccionador

The manufacturer assumes no responsibility for unfavourable consequence resulting from the non-application or incorrect application of the instructions provided herein.

El fabricante no asume ninguna responsabilidad por consecuencias desfavorables que resulten de no seguir las instrucciones, precaucionesy advertencias proporcionadas en este documento.

Le fabriquant ne saurait être tenu pour responsible des conséquences entraînées par toute utilization allant à l'encontre des instructions inclues dans ce manuel.

NOARK

WARNING

Do not attempt to install or perform maintenance on equipment while it is energized. Death, severe personal injury, or substantial property damage can result from contact with energized equipment. Always verify that no voltage is present before proceeding with this task, and always follow generally accepted safety procedures.
NOARK is not liable for the misapplication or misapplication of its products.

Veuillez ne pas tenter de faire d'installation ou de maintien sur l'équipement quand il est branché. Les contacts avec l'équipement branché pourra provoquer des morts, des blessures grâves personnelles ou du dommage à la propriété. Veuillez toujours être sûre qu'il n'y pas de tension avant d' exécuter cette mission et respecter les processus de sécurités acceptés généralement.
NOARK n'est pas responsable des fausses manoeuvres de ses produits.

Trabajando en o cerca de equipo energizado puede resultar en riesgo de muerte, daños corporales severas o daños a la propiedad.Asegúrese que la máquina no esté energizada antes de instalaro realizar el mantenimiento. Y siempre siga los procedimientos de seguridad aceptados.
NOARK no es responsable de la mala aplicación de sus productos.

NOARK

A

in (mm)



x4

SH1 ST2.9X16 5.3 lb.in (0.6N· m)





B



OK



OK



Clearances per UL98

Minimum distances to enclosure walls





Minimum enclosure size or equivalent volume UL98

	Height	Width	Depth
in	7.89	8.03	3.94
mm	200.5	204	100

Minimum distances to enclosure walls

	A	B	C
in	2	2.4	0.9
mm	50	60.8	22

Warning

A minimum distance of 25.4mm (1 in) from current carried parts to any conductive part.

NOARK

C



SH1



OFF

D

in (mm)



SH1

NOARK

E

in (mm)



G



H



Notes

The instructions for installation, testing, maintenance, or repair herein are provided for the use of the product in general commercial applications and may not be appropriate for use in nuclear applications. Additional instructions may be available upon specific request to replace, amend, or supplement these instructions to qualify them for use with the product in safety-related applications in a nuclear facility.

This Instruction Booklet is published solely for information purposes and should not be considered all-inclusive. If further information is required, you should consult an authorized NOARK sales representative.

The sale of the product shown in this literature is subject to the terms and conditions outlined in appropriate NOARK selling policies or other contractual agreement between the parties. This literature is not intended to and does not enlarge or add to any such contact. The sole source governing the rights and remedies of and purchaser of this equipment is the contract between the purchaser and NOARK.

NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, OR WARRANTIES ARISING FROM COURSE OF DEALING OR USAGE OF TRADE, ARE MADE REGARDING THE INFORMATION, RECOMMENDATIONS, AND DESCRIPTIONS CONTAINED HEREIN.

In no event will NOARK be responsible to the purchaser or user in contact in tort (including negligence), strict liability or otherwise for any special indirect incidental or consequential damage or loss whatsoever including but not limited to damage or loss of use of equipment plant or power system cost of capital loss of power additional expenses in the use of existing power facilities or claims against the purchaser or user by its customers resultingfrom the use of the information recommendations and description contained herein.

In order to protect the environment, when the product or its components are scrapped, please dispose of it as industrial waste or hand it over to the recycling station for disaggregation, recycling and reuse according to relevant national regulations.

Printed with environment-friendly paper

Copyright Noark. All Rights Reserved
http://na.noark-electric.com
ZRDS1D202412UL